

FOR CONCRETE FLOORS WHEN USING PENETRATING SEALER

TOOL STEPS	MATTE FINISH			SEMIGLOSS			GLOSS		
	CREAM	SALT & PEPPER	AGGREGATE	CREAM	SALT & PEPPER	AGGREGATE	CREAM	SALT & PEPPER	AGGREGATE
1. HYPERCUT PCD			X OR X			X OR X			X OR X
2. HYPERGRIND MB		X OR X			X OR X			X OR X	
3. 16/18 GRIT TITANIUM MB			X			X			X
4. 30/40 GRIT TITANIUM MB		X	X		X	X		X	
5. 60/80 GRIT TITANIUM MB		X			X			X	X
6. 100 GRIT SHARK MB RESIN		X	X		X	X		X	X
7. 100 GRIT HYPERGLOSS RESIN	X	X	X	X	X	X	X	X	X
8. 200 GRIT HYPERGLOSS RESIN	X	X	X	X	X	X	X	X	X
9. 400 GRIT HYPERGLOSS RESIN				X	X	X	X	X	X
10. 800 GRIT HYPERSHINE PAD				X	X	X	X	X	X
11. 1500 GRIT HYPERSHINE PAD							X	X	X
12. 3000 GRIT HYPERSHINE PAD							X	X	X
CHEMICAL STEPS									
1. PORE FILLER OR DENSIFIER	X	X	X	X	X	X	X	X	X
2. AQUASEAL PENETRATING SEALER	X	X	X	X	X	X	X	X	X

FOR CONCRETE FLOORS WHEN USING SURFACE SEALER

TOOL STEPS	MATTE FINISH			SEMIGLOSS			GLOSS		
	CREAM	SALT & PEPPER	AGGREGATE	CREAM	SALT & PEPPER	AGGREGATE	CREAM	SALT & PEPPER	AGGREGATE
1. HYPERCUT PCD			X OR X			X OR X			X OR X
2. HYPERGRIND MB		X OR X			X OR X			X OR X	
3. 16/18 GRIT TITANIUM MB			X			X			X
4. 30/40 GRIT TITANIUM MB		X	X		X	X		X	
5. 60/80 GRIT TITANIUM MB		X			X			X	X
6. 100 GRIT SHARK MB RESIN		X	X		X	X		X	X
7. 100 GRIT HYPERGLOSS RESIN	X	X	X	X	X	X	X	X	X
8. 200 GRIT HYPERGLOSS RESIN	X	X	X	X	X	X	X	X	X
9. 400 GRIT HYPERGLOSS RESIN				X	X	X	X	X	X
10. 800 GRIT HYPERSHINE PAD				X	X	X	X	X	X
11. 1500 GRIT HYPERSHINE PAD							X	X	X
12. 3000 GRIT HYPERSHINE PAD							X	X	X
CHEMICAL STEPS									
1. PORE FILLER OR DENSIFIER	X	X	X	X	X	X	X	X	X
2. PROGUARD PRIMER				X	X	X	X	X	X
3. PROGUARD COAT & SEAL				X	X	X	X	X	X